

Meraki Go - Decoding the Access Point LED Light

Each Meraki Go WiFi access point is equipped with a multi color light that can be seen on the top right of each device to provide an easy at-a-glance status.



If you don't see any light being emitted, please ensure that your Meraki Go access point is properly powered with either the included AC adapter, or from a "power over ethernet" (PoE) supported ethernet port.


Color States

These can also be found from within the Meraki Go App.

	Orange	Booting Your access point is powered on and starting up
	Blinking Orange	Cannot find uplink Your access point is unable to find a way to the internet. This can occur when there are issues with your internet service or if your network is misconfigured
	Multi-color	Connecting Your access point is initializing and trying to connect to the internet
	Blinking blue	Updating Your access point is updating to the latest firmware. Firmware updates include new features and bug fixes
	Green	Online Your access point is online and ready for device to connect. It's good to Go!

LED Locations

Indoor WiFi Access Point



Outdoor WiFi Access Point

